



HARDBODY PICKUP D21

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
1991-97	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3438050

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
1991-97	3438050	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
1986-97	D21, 2.7L, Diesel, Left Side Mount Refer to www.safari4x4.com.au for details.	SS700HF

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>	
D21 Models	Front	Medium Load (over 110lbs)	Torsion		1	303008 ¹	
			Shock		2	N58 ²	
	Rear	Medium Load (0lbs to GVW)	Spring	1.0"	2	CS030R	
			Shock		2	N56	
			Heavy Constant Load (800lbs)	Spring	1.0"	2	CS031R
				Shock		2	N59
Installation		Steering Damper			1	OMESD35	
		Spring Bushing Kit			2	OMESB81	
		Ubolts			4	OMEU63	

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² It may be necessary to slightly increase the clearance in the front wishbone to allow shock absorber to fit. Do not modify shock absorber.

*Firmer shock.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1986 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107
1986 On	Rear	H233B, 31 spline, 6 Cyl.	32.4 (1.20")	31	ALL	RD09 ²
		H233B, 33 spline, 6 Cyl.	33.3 (1.31")	33	ALL	RD24 ²
1986-97	Rear	C200, 29 spline, 4 Cyl.	30.4 (1.20")	29	ALL	RD107 ^{1,2}

¹ Only suitable for differentials with 12mm crown wheel bolts.

² Refer to dealer or check spline count to determine axle type.