



MONTERO / PAJERO

MITSUBISHI

ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
1981-88	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3434010

IPF LIGHTS & LIGHTING ACCESSORIES

Year	Type	Recommended Lighting
1981-88	ALL	800XSD, 900XS, 900HID, 960 S/R, 868CS, 968CS, J-01
1991-00	ALL	800XSD, 868CS

SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
To 1990	3.0L V6/2.5L Diesel Snorkel	SS20HF

OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.
1991-99	Front	Stock/Light Load	Torsion ¹		1	303010/11 ³
			Shock		2	N18
1991-99	Rear	LWB Rear Coil Spring - Medium Load (0lbs to GVW)	Spring	.50"	2	OME910 ²
			Shock		2	N64
1991-99	Rear	LWB Rear Coil Spring - Heavy Constant Load (440lbs+)	Spring	.50"	2	OME938 ²
			Shock		2	N64
¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bumps stop clearance. ² Coils must be installed with progressive rate to the top. ³ 303010 for 91-94 with 1278mm length torsion bars, 303011 for 95-00 with 1308mm length bars						
1989-91	Front	Stock/Light Load	Torsion ¹		1	303010 ¹
			Shock		2	N60G
1989-91	Rear	Rear Coil Spring - Medium Load	Spring	.50"	2	OME910 ²
			Shock		2	N62G
1989-91	Installation	Steering Damper - For Rear Coil Spring Models			1	OMESD17 ³
¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bumps stop clearance. ² Coils must be installed with progressive rate to the top. ³ OMESD17 only fits non power steering models.						
To 1991	Front	Stock/Light Load	Torsion ¹		1	303009 ¹
			Shock		2	N60G
To 1991	Rear	Rear Leaf Spring - Medium Load	Spring	1.50"	2	CS022R
			Shock		2	*N56/N54
To 1991	Rear	Rear Leaf Spring - Constant Heavy Load (550lbs+)	Spring	1.50"	2	CS023R
			Shock		2	N56
To 1991	Installation	Leaf Spring Bushing Kit			2	OMESB8 ²
		U Bolts			4	OMEU54 ³
		Steering Damper			1	OMESD17 ⁴
¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance. ² OMESB8 must be used with CS022R & CS023R springs. ³ OMEU54 only required on SWB models. ⁴ OMESD17 only fits non power steering models.						

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1991-99	Front	IFS, 28 Spline		28	ALL	RD110 ⁴
1983-86	Rear	Small ¹ Differential	30.5 (1.20")	28	ALL	RD05
1987-95	Rear	Large ² Differential Disc Brake	30.5 (1.20")	28	ALL	RD25 ³
		Large ² Differential Drum Brake	30.5 (1.20")	28	ALL	RD46 ⁴

¹ Small differential has a crown wheel spigot diameter of 124mm.

² Large differential has a crown wheel spigot diameter of 145mm.

³ Will not fit turbo diesel with intercooler or 3500cc petrol vehicles

⁴ Will not fit Pajero/Montero 3000cc automatic.