



# NISSAN

## PATROL GU Y61

### ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
All	Winch Bar	with fender flares	12000lb, 10000lb, 9500lb & 9000lb	3417100
All	Winch Bar	without fender flares	12000lb, 10000lb, 9500lb & 9000lb	3417110
All	Sahara Bar	with fender flares	9000lb & 9500lb	3917030

### IPF LIGHTS & LIGHTING ACCESSORIES

Year	Type	Recommended Lighting
All	All	800XSD, 900HID, 900XSS, 900XSD

### SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
All	All models except 3.0/4.2 Turbo Diesel Intercooled	SS15HF
All	3.0/4.2 Turbo Diesel Intercooled Models	SS16HF

Refer to [www.safari4x4.com.au](http://www.safari4x4.com.au) for details.

### OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.
GU Y61 with LWB	Front	Petrol 4.5 & Diesel 4.2 Engines to 110lbs	Spring	2"	2	OME970
			Shock		2	*N19/N19C
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Caster Kit			1	OMECA77B <sup>2</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Load 110 - 240lbs	Spring	2"	2	OME971
			Shock		2	N19
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Caster Kit			1	OMECA77B <sup>2</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Low Height to 110lbs	Spring	.75"	2	OME972
			Shock		2	*N19/N19C
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Diesel 2.8 & 3L,4C Turbo to 110lbs	Spring	2"	2	OME973
			Shock		2	*N19/N19C
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Caster Kit			1	OMECA77B <sup>2</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>

**OLD MAN EMU SUSPENSION PRODUCTS**

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
	Front	Load 110 - 240lbs	Spring	2"	2	OME970
			Shock		2	N19
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Caster Kit			1	OMECA77B <sup>2</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Low Height to 110lbs	Spring	.75"	2	OME974
			Shock		2	*N19/N19C
	Installation	Steering Damper			1	OMESD11 <sup>5</sup>
		Steering Damper			1	OMESD01 <sup>5</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
ALL	Rear	Medium Load to GVW	Spring	2"	2	OME980 <sup>4</sup>
			Shock		2	*N29/N29C
	Installation	Sway Bar Extension				FK18 <sup>3</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Rear	Constant Load 440lbs to GVW	Spring	2"	2	OME981 <sup>4</sup>
			Shock		2	*N29/N29C
	Installation	Sway Bar Extension				FK18 <sup>3</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Rear	Low Height Med Load to GVW	Spring	1"	2	OME982 <sup>4</sup>
			Shock		2	*N29/N29C
	Installation	Sway Bar Extension				FK18 <sup>3</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
<sup>1</sup> Coil trim packers may be required to trim vehicles. Packers must be installed to the:Top on rear coils, bottom on the front coils.						
<sup>2</sup> OMECA77B caster kit will increas caster angle by 2". Check manufacturer's specifications to determine if OMECA77B kit is required.						
<sup>3</sup> FK18: rear sway bar extension bracket is mandatory fitment to prevent damage to sway bar when suspension is at full extension.						
<sup>4</sup> Special Note: due to limited clearance between tailshaft and chassis cross member. OME does not recommend fitment of gear box packers.						
<sup>5</sup> OMESD11 steering damper fits all models up to 1/2000. OMESD01 fits 2/2000 models on.						
GU Y61 Cab	Front	All 4.2 Diesel, Load to 110lbs	Spring	2"	2	OME970
Chassis Coil			Shock		2	*N19/N19C
Front, Leaf	Installation	Steering Damper			1	OMESD11
Rear		Caster Kit			1	OMECA77B <sup>2</sup>
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Load 110 - 240lbs	Spring	2'	2	OME971
			Shock		2	N19
	Installation	Steering Damper			1	OMESD11
		Trim Packer				OMEGQPF05 <sup>1</sup>
		Trim Packer				OMEGQPF10 <sup>1</sup>

**OLD MAN EMU SUSPENSION PRODUCTS**

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>	
All Models	Rear	Medium Load to GVW	Spring	2"	2	OME61A/B	
			Shock		2	N25	
	Installation		Bush Kit			2	OMESB64
			Anti Inversion			1	FK08 <sup>3</sup>
			Greasable Shackles			1	OMECS1
			Greasable Shackles			1	OMEGP2
	Rear	Constant Load 440lbs to GVW	Spring	2"	2	CS016RA/B	
			Shock		2	N25	
	Installation		Bush Kit			2	OMESB64
			Anti Inversion		1		FK08 <sup>3</sup>
Greasable Shackles					1	OMECS1	
Greasable Shackles					1	OMEGP2	
<sup>1</sup> Coil trim packers may be required to trim vehicles to a maximum of .59" per coil. Packers must be installed to the bottom on front coils. Front: Part No. OMEGQPF10 = .39" & OMEGQPF05 = .20"							
<sup>2</sup> OMECA77B caster kit will increase caster angle by 2°. Caster angle will be affected when raising vehicle. Check Manufacturer's specifications to determine if OMECA77B is required.							
<sup>3</sup> FK08 anti inversion kit is mandatory fitment if greasable shackles are not fitted. Refer to OME fitting manual.							
GU Y61, Coil Cab Chassis	Front	All 4.2 Diesel, Load to 110lbs	Spring	2"	2	OME970	
			Shock		2	*N19/N19C	
	Installation		Steering Damper			1	OMESD11
			Caster Kit			1	OMECA77B <sup>2</sup>
			Trim Packer				OMEGQPF05 <sup>1</sup>
			Trim Packer				OMEGQPF10 <sup>1</sup>
	Front	Heavy Load 110 - 240lbs	Spring	2"	2	OME971	
			Shock		2	N19	
	Installation		Steering Damper			1	OMESD11
			Caster Kit			1	OMECA77B <sup>2</sup>
Trim Packer						OMEGQPF05 <sup>1</sup>	
Trim Packer						OMEGQPF10 <sup>1</sup>	
ALL	Rear	To GVW	Spring	2"	2	OME983	
			Shock		2	N29	
	Installation		Fitting Kit			1	FK18 <sup>3</sup>
			Trim Packer				OMEGQPF05 <sup>1</sup>
			Trim Packer				OMEGQPF10 <sup>1</sup>
	Rear	Constant Load 440lbs to GVW	Spring	2"	2	OME984	
			Shock		2	N29	
	Installation		Fitting Kit			1	FK18 <sup>3</sup>
			Trim Packer				OMEGQPF05 <sup>1</sup>
			Trim Packer				OMEGQPF10 <sup>1</sup>
Rear	Constant Load 880lbs to GVW	Spring	2"	2	OME985		
		Shock		2	N29		
Installation		Fitting Kit			1	FK18 <sup>3</sup>	
		Trim Packer				OMEGQPF05 <sup>1</sup>	
		Trim Packer				OMEGQPF10 <sup>1</sup>	

<sup>1</sup> OMECA77B caster kit will increase caster angle by 2°

<sup>2</sup> Coil trim packers may be required to trim vehicle to a maximum of .59". Packers must be installed to the bottom on front coils and top of rear

<sup>3</sup> FK18 rear sway bar extension bracket in mandatory fitment to prevent damage to sway bar when suspension is at full extension.

**ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES**

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1998 On	Front	H233B	32 (1.26")	31	All	RD78A
	Rear	H233B 'small'	33.3 (1.31")	33	All	RD17 <sup>2</sup>
		H260 'large'	38.4 (1.51")	37	All	RD71 <sup>2</sup>

<sup>1</sup> Only suitable for differentials with 12mm ring gear bolts.

<sup>2</sup> Refer to dealer or check spline count to determine axle type.

**ARB ROOF RACKS**

<u>Models</u>	<u>Recommended Roof Racks</u>	<u>Part No.</u>
GU LWB and SWB	87x49" Rack with Mesh Floor	3800010M
	87x49" Rack without Mesh Floor	3800010
	87x49" Touring Rack for Roof Top Tent	3800200
	Fitting Kit for 87x49" racks	3700050
	73x49" With Mesh Floor	3800020M
	73x49" Without Mesh Floor	3800020
	Fitting Kit for 73x49" racks	3700050
	43x49" With Mesh Floor	3800030M
	40x49" Rack without Mesh Floor for GU/Y61 Cab Chassis	3800150
	Fitting Kit for 43x49" and 40x49" racks	3700060
	Wind Deflector for 49" wide Roof Rack	3700310
	Hi-lift Jack and Shovel holder for ARB Roof Rack	K6202

\*\*use 43x49" rack for SWB Vehicles with Steel Roof