

ARB DELUXE BULL BARS & WINCH BARS

YEAR	MODEL	FEATURES	WINCHES	PART NO.
1995-04	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS, BLACK	9.5XP, HS9500, XD9000, M8000	3423020
2005-11	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS ² , URETHANE BUFFERS, BLACK	9.5XP, HS9500, XD9000, M8000	3423030 ²
2005-11	WINCH BAR	AIRBAG APPROVED, OPTIONAL ARB FOG LIGHTS ¹ , RECESSED INDICATORS ² , URETHANE BUFFERS, BLACK	9.5XP, HS9500, XD9000, M8000	3423130 ²
2012-14	WINCH BAR	AIRBAG APPROVED, OPTIONAL ARB FOG LIGHTS ¹ , RECESSED INDICATORS ² , URETHANE BUFFERS, BLACK	9.5XP, HS9500, XD9000, M8000	3423140 ²

¹ ARB FOG LAMP KIT PART NO. 6821201. 3500440 LOOM REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS. ARB BUMPER WILL NOT ACCEPT FACTORY FOG LIGHTS.

² SOME VEHICLES MAY NEED 1156 LED BULBS INSTALLED IN ARB BUMPER IN ORDER FOR TURN SIGNALS TO WORK PROPERLY

IPF LIGHTING & ACCESSORIES

YEAR	MODEL	RECOMMENDED LIGHTING
1995-04	3423020	ARB INTENSITY LED, 900DB, 800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2005-11	3423030	ARB INTENSITY LED, 900DB, 800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2005-11	3423130	ARB INTENSITY LED, 900DB, 800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2012-14	3423140	ARB INTENSITY LED, 900DB, 800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG

SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
1995-04	TOYOTA TACOMA V6 SNORKEL	SS170HF
2005-14	NOT AVAILABLE	N/A

REFER TO WWW.SAFARI4X4.COM.AU FOR DETAILS.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1996-04	FRONT	7.5" DIA. RG, 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
2005-14	FRONT	8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.91 & UP	RD111
		8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.73 & DN	RD121
1996-14	REAR	8.4" DIA. RG, 12 BOLT	33 (1.31")	30	ALL	RD129

**THESE LOCKERS SUIT OPEN DIFFERENTIALS ONLY, AND WILL NOT REPLACE THE FACTORY E-LOCKER UNLESS THE HOUSING AND 3RD MEMBER ARE REPLACED WITH OPEN END DIFFS.

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1998-04	COMPLETE KITS	STOCK/LIGHT LOAD (0-110LBS)	KIT	2"	1	OMETAC04LKS ⁶
		HEAVY LOAD (110-220LBS)	KIT	2"	1	OMETAC04HKS ⁶
	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.75"	1	2880 ¹
		NITROCHARGER SPORT	STRUT		2	90004
		HEAVY LOAD (110-220LBS)	SPRING	1.75"	1	2881 ¹
		NITROCHARGER SPORT	STRUT		2	90004
	REAR	MEDIUM LOAD	SPRING	2.25"	2	CS046RA/B ²
		NITROCHARGER SPORT	SHOCK			*60065/60062
		NITROCHARGER	SHOCK		2	*N85/N94
	REQ'D FOR INSTALLATION	REAR LEAF SPRING BUSHING KIT			2	OMESB89 ³
		EXHAUST BRACKET			1	FK21 ⁴
	OPTIONAL	FRONT TRIM SPACER 5MM			1	OME95PF5
		REAR GREASABLE SHACKLE KIT			1	OMEGS12 ³
		REAR GREASABLE BUSHING KIT			2	OMESB88 ³
		EXTRA LEAF			2	D6XL ⁷

¹ OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

² FOR LIGHT LOAD APPLICATIONS, THE 2ND LEAF FROM THE BOTTOM OF THE SPRING PACK CAN BE REMOVED FOR IMPROVED RIDE COMFORT. CS046RA/B REAR LEAF SPRINGS ONLY FIT POST 1998 XTRA CAB AND DOUBLE CAB MODELS.

³ OMESB89 MUST BE USED WITH ORIGINAL SHACKLES. OMESB88 MUST BE USED WITH OMEGS12 GREASABLE SHACKLES. OE RUBBER BUSHINGS ARE USED AT FIXED END OF SPRING. INSTALL ORIGINAL OE BUSHINGS FROM OE SPRINGS IF THEY ARE IN GOOD CONDITION, OR SOURCE NEW OE BUSHINGS FROM DEALERSHIP.

⁴ FK21 EXHAUST BRACKET IS A MANDATORY FITMENT TO ENSURE EXHAUST SYSTEM CLEARS SPRINGS.

⁵ KIT CONTAINS STANDARD OLD MAN EMU NITROCHARGER SHOCKS

⁶ KIT CONTAINS OLD MAN EMU NITROCHARGER SPORT SHOCKS

⁷ ADD EXTRA LEAF TO REAR SPRING PACK WHEN CARRYING 220LBS AS A HEAVY CONSTANT LOAD.

* FIRMER SHOCK

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
2005-14	COMPLETE KITS	STOCK/LIGHT LOAD (0-110LBS)	KIT	2"	1	OMETAC05LKS ^{1,5}
		HEAVY LOAD (110-220LBS)	KIT	2"	1	OMETAC05HKS ^{1,5}
	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.75"	1	2885 ⁴
		NITROCHARGER SPORT	STRUT		2	90021
		NITROCHARGER	STRUT		2	N140S
		HEAVY LOAD (110-220LBS)	SPRING	1.75"	1	2886 ⁴
		NITROCHARGER SPORT	STRUT		2	90000
		NITROCHARGER	STRUT		2	N140S
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.75"	2	CS047R ¹
		NITROCHARGER SPORT	SHOCK		2	60091
		NITROCHARGER SHOCK	SHOCK		2	N182
	REQ'D FOR INSTALLATION	FITTING KIT			1	FK29 ³
		U BOLTS			4	OMEU53A
	OPTIONAL	EXTRA LEAF			2	D29XL ²
		REAR SPRING BUSHING KIT			2	OMESB108 ¹
TRIM PACKER ⁶					OME95PF5 ⁶	

¹ OMESB108 BUSHING KIT OR FACTORY TOYOTA PART NUMBER 90389-A0003 (QUANTITY OF 4 TOTAL) REQUIRED WHEN FITTING CS047R LEAF SPRINGS.

² ADD XL TO RAISE SPRING 15MM AND INCREASE RATE. REMOVED LEAF 3 TO LOWER SPRING 15MM AND REDUCE RATE

³ DRIVESHAFT PACKER KIT IS DESIGNED TO SPACE DOWN CARRIER BEARING TO REDUCE TAIL SHAFT FLANGE ANGLE, THEREBY REDUCING DRIVELINE VIBRATION.

⁴ OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

⁵ KIT CONTAINS STANDARD OLD MAN EMU NITROCHARGER SPORT SHOCKS AND STRUTS

⁶ TRIM PACKER PART No. OME95PF5 IS DESIGNED TO TRIM VEHICLE FROM DRIVER TO PASSENGER SIDE. NOT TO BE USED FOR ADDITIONAL LIFT.