



# TOYOTA / LEXUS

## LAND CRUISER 100 SERIES & LEXUS LX470

### ARB DELUXE BULL BARS & WINCH BARS

#### Including Air Bag Equipped Models

Year	Type	Features	Winches	Part No.
2003-07	Sahara Bar	Airbag Approved, Recessed Indicators, Urethane Buffers, Tow Points <sup>3</sup> , Recessed Fog lamps <sup>5</sup> , Grey	M12000, M10000 <sup>1</sup> , XD9000, M8000	3913060
2002-07	Combo Bar (LC100 only)	Airbag Approved, Recessed Indicators, Urethane Buffers, Tow Points <sup>3</sup> , Recessed Fog lamps <sup>5</sup> , Black	M12000, M10000 <sup>1</sup> , XD9000, M8000	3413090 <sup>4</sup>
1998-02	Sahara Bar	Airbag Approved, Recessed Indicators, Urethane Buffers, Tow Points <sup>3</sup> , Recessed Fog lamps <sup>5</sup> , Grey	XD9000, M8000	3913040
1998-02	Combo Bar (LC100 only)	Airbag Approved, Recessed Indicators, Tow Points <sup>3</sup> , Split Pan, Black	M12000, M10000 <sup>1</sup> , HS9500, XD9000 <sup>2</sup> , M8000 <sup>2</sup>	3413050 <sup>4</sup>

<sup>1</sup> Only available through ARB USA - ARB part no. US20801.

<sup>2</sup> Fitment of Warn XD9000 & M8000 winch requires special spacer kit - ARB part no. 3500050.

<sup>3</sup> Utilizes original equipment tow points.

<sup>4</sup> The Lexus LX470 will only accept Sahara Bar models.

<sup>5</sup> Optional on this model - ARB part no. 9249FCK.

\*Firmer shock.

### IPF LIGHTS & LIGHTING ACCESSORIES

Year	Part No.	Recommended Lighting
1998-07	ALL	800XSD, 900XS, 900HID, 930S/R, 960S/R, 868CS, 968CS, J-01

### ARB SIDE RAILS & STEPS

Year	Model	Description	Part No.
1998-02	IFS Models to 10/02	Two-piece side protection rails and steps (both parts required, as well as ARB bumper for mounting), Black	4413250, 4413260
2002-07	IFS Models 11/02 on	Two-piece side protection rails and steps (both parts required, as well as ARB bumper for mounting), Black	4413270, 4413260

### ARB REAR PROTECTION BARS

Year	Type	Item	Part No.	
1998-07	LC100	Deluxe Rear Bar, Grey Powdercoat	5613010 <sup>1</sup>	
		LHS blank cover panel, Grey	5700031 <sup>2</sup>	
		RHS blank cover panel, Grey	5700032 <sup>2</sup>	
		LHS tire carrier, Grey	5700011 <sup>2</sup>	
		RHS tire carrier, Grey	5700012 <sup>2</sup>	
		LHS jerry can holder, Grey	5700021 <sup>2</sup>	
		RHS jerry can holder, Grey	5700022 <sup>2</sup>	
		Optional	LHS camp light	5700041
		Optional	RHS camp light	5700042
		Optional	Antenna mount	5700050
Optional	Hilift mount for wheel carrier only	5700060		
Optional	Reversing light kit	5700070		
Optional	Axe and Shovel mount (mounts on wheel carrier)	5700080		

<sup>1</sup> A left or right hand side cover panel must be used for installation if tire carrier or jerry can holder is not purchased.

<sup>2</sup> Customer can use a combination of blanks, tire carriers, or jerry can holders for a complete installation. **A minimum of 3 separate part numbers will be required for this bar to mount to the vehicle.**

\*\*\* Contact ARB with any questions before ordering

**SAFARI SNORKELS**

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
4/1998-07	All models	SS85HF

**OLD MAN EMU SUSPENSION PRODUCTS**

<u>Year</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
1998-07	Front	Stock/Light Load IFS	Torsion Bar	N/A	1	303001/2 <sup>1</sup>
			Shock		2	*N133/N100
1998-00	Rear	100 Series IFS - Medium Load (0lbs to GVW)	Spring	1.50"	2	OME865
			Shock		2	*N101/N101C
		100 Series IFS - Heavy Constant (440lbs to GVW)	Spring	1.50"	2	OME864
			Shock		2	N101
2000-07	Rear	100 Series IFS - Medium Load (0lbs to GVW)	Spring	2.0"	2	OME860
			Shock		2	*N101/N101C
		100 Series IFS - Heavy Constant (440lbs to GVW)	Spring	3.0"	2	OME863
			Shock		2	N101
	Optional	Rear Shock Stone Guard			1	OME661 <sup>2</sup>
		Rear Trim Spacer 5mm				OME80PR05 <sup>3</sup>
	Rear Trim Spacer 10mm				OME80PR10 <sup>3</sup>	

<sup>1</sup> 303001 suits V8 models, 303002 suits Turbo Diesel models. Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

<sup>2</sup> OME660 lower shock mount stone guard is recommended fitment to rear shocks to protect against severe stone peppering encountered on loose road surfaces.

<sup>3</sup> Trim vehicle to a maximum of 15mm per coil. Spacers must be installed on top of coils.

**ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES**

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1998-07	Front	8" dia. RG, IFS, 50mm bearing ID	33 (1.31")	30	ALL	RD92
	Rear	All models	34.8 (1.37")	32	ALL	RD64

**ARB ROOF RACKS**

<u>Models</u>	<u>Recommended Roof Racks</u>	<u>Part No.</u>
100 Series	70x44" Rack with Mesh Floor <sup>1</sup>	3813010M
	70x44" Rack without Mesh Floor <sup>1</sup>	3813010
	70x44" Touring Rack to hold Roof Top Tent <sup>1</sup>	3813200
	Roof Rack Fit Kit for 70x44" Rack LC100 Series <sup>1</sup>	3713010
	44x44" Rack with Mesh Floor	3813020M
	44x44" Rack without Mesh Floor	3813020
	Roof Rack Fit Kit for 44x44" Rack LC100 Series	3713020
	Wind Deflector for 44" wide Roof Rack	3700320
	Hi-lift Jack and Shovel holder for ARB Roof Rack	K6202

<sup>1</sup> Contact ARB for Information Regarding OE Vehicle Production Variations Which May Effect Proper Rack Fitment