

## SANTANA SAMURAI TO 2004 SWB & LWB MODELS

<b>FRONT</b> <i>Estimated Lift: 30 - 40mm</i>	1.3 LITRE PETROL			1.9 LITRE DIESEL		
	PART NUMBER	QTY	UNIT PRICE \$	PART NUMBER	QTY	UNIT PRICE \$
<b>SPRING: TO 25 KGS - 40mm</b>	<b>CS012FA / B</b>	1 + 1		<b>CS013FA / B</b>	1 + 1	
NITROCHARGER	OME034	2		OME034	2	
<b>SPRING: 26 TO 75 KGS</b>	<b>CS013FA / B</b> <span style="border: 1px solid black; padding: 0 2px;">1</span>	1 + 1		<b>CS013FA / B</b> <span style="border: 1px solid black; padding: 0 2px;">1</span>	1 + 1	
NITROCHARGER	OME034	2		OME034	2	
SPRING BUSH	OMESB19	2		OMESB19	2	
U BOLTS	OE <span style="border: 1px solid black; padding: 0 2px;">2</span>			OE <span style="border: 1px solid black; padding: 0 2px;">2</span>	4	
STEERING DAMPER	OMESD30 <span style="border: 1px solid black; padding: 0 2px;">3</span>	1		OMESD30 <span style="border: 1px solid black; padding: 0 2px;">3</span>	1	
TRIM PACKER	TP05			TP05		

<b>REAR</b> <i>Estimated Lift: 40mm</i>	SWB MODELS			LWB MODELS		
	PART NUMBER	QTY	UNIT PRICE \$	PART NUMBER	QTY	UNIT PRICE \$
<b>SPRING: MEDIUM LOAD</b>	<b>CS038R</b>	2		<b>CS039R</b>	2	
NITROCHARGER	OME035	2		OME035	2	
<b>SPRING: CONSTANT 100KGS</b>	<b>CS039R</b>	2		<b>CS039R</b> <span style="border: 1px solid black; padding: 0 2px;">4</span>	2	
NITROCHARGER	OME035	2		OME035	2	
SPRING BUSH KIT	OMESB19	2		OMESB19	2	
U BOLTS	OE <span style="border: 1px solid black; padding: 0 2px;">2</span>			OE <span style="border: 1px solid black; padding: 0 2px;">2</span>		
TRIM PACKER	TP05			TP05		

**REMARKS:**

- 1 Fitment of XL Leaf D20XL is recommended for weight in excess of 26kg on diesel model & 75 kg on petrol model.
- 2 Front: LHS: OMEU60 x 2, RHS: OMEU61B x 2 Required when fitting CS013FA/B  
Rear: OMEU60 x 4 Required when fitting CS039R.
- 3 OMESD30 can be fitted to models which have an OE Steering Damper.
- 4 Fitment of XL Leaf D21XL is recommended for LWB models with constant 100kg rear weight or OE hard top.

## JIMNY SN413

<b>FRONT</b> <i>Estimated Lift: 40mm</i>	4 CYLINDER PETROL ENGINE			DIESEL ENGINE		
	PART NUMBER	QTY	UNIT PRICE \$	PART NUMBER	QTY	UNIT PRICE \$
<b>SPRING: TO 35 KGS</b>	<b>OME963</b>	2		<b>OME965</b>	2	
NITROCHARGER	OME028	2		OME028	2	
<b>SPRING: 36 TO 85 KGS</b>	<b>OME965</b>	2		<b>OME969</b>	2	
NITROCHARGER	OME028	2		OME028	2	

<b>REAR</b> <i>Estimated Lift: 40mm</i>	ALL MODELS		
	PART NUMBER	QTY	UNIT PRICE \$
<b>SPRING:</b>	<b>OME966</b> <span style="border: 1px solid black; padding: 0 2px;">1</span>	2	
	<b>OME967</b>		
NITROCHARGER	OME029	2	
TRIM PACKER	OMESJR10		

**REMARKS:**

- 1 OME966 suits Japanese built models with a 20mm higher right hand side coil.  
OME967 suits European built models with equal height coils