

## PATHFINDER (USA MODELS ONLY)

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
2008-12	WINCH BAR	AIRBAG APPROVED, OPTIONAL RECESSED FOG LAMP PROVISION <sup>3</sup> , URETHANE BUFFERS, TOW POINTS <sup>2</sup> , BLACK	HS9500, XD9000, M8000, M6000	3438290
2005-07	WINCH BAR	AIRBAG APPROVED, OPTIONAL RECESSED FOG LAMP PROVISIONS <sup>3</sup> , URETHANE BUFFERS, TOW POINTS <sup>2</sup> , BLACK	HS9500, XD9000, M8000, M6000	3438260
2000-02	SAHARA BAR	AIRBAG APPROVED, RECESSED FOG LAMP PROVISION <sup>1</sup> , URETHANE BUFFERS, TOW POINTS <sup>2</sup> , GREY	HS9500, XD9000, M8000, M6000	3938020

<sup>1</sup> OPTIONAL ON THIS MODEL - ARB PART NO. 9381FCK

<sup>2</sup> UTILIZES ORIGINAL EQUIPMENT TOW POINTS.

<sup>3</sup> OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 LOOM REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS

\* DISCONTINUED BAR

IPF LIGHTING & ACCESSORIES		
YEAR	TYPE	RECOMMENDED LIGHTING
2008-12	3438290	800XSD, 901XSD, 901XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2005-07	3438260	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2000-02	3938020	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG

SAFARI SNORKEL		
YEAR	RECOMMENDED SNORKEL	PART NO.
1986-97	D21, 2.7L, DIESEL, LEFT SIDE MOUNT	SS700HF

REFER TO [WWW.SAFARI4x4.COM.AU](http://WWW.SAFARI4x4.COM.AU) FOR DETAILS.

OLD MAN EMU SUSPENSION SYSTEMS						
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1996-04 R50 MODELS	FRONT	STOCK/LIGHT LOAD (0-60LBS)	SPRING	.50"	1	2921
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	FRONT	MEDIUM LOAD (50-110LBS)	SPRING	.50"	1	2923
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	FRONT	HEAVY LOAD (110-220LBS)	SPRING	.50"	1	2928
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	.50"	1	2922
		MEDIUM LOAD (TO 1/1999)	SHOCK		2	*N61
		MEDIUM LOAD TO (FROM 2/1999)	SHOCK		2	*N104
1987-95	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	N/A	N/A	N/A <sup>1</sup>
			SHOCK		2	N26F
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	.75"	1	2920
			SHOCK		2	*N42/N89
REQUIRED		STEERING DAMPER			1	OMESD35

<sup>1</sup> ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.

<sup>2</sup> IT MAY BE NECESSARY TO SLIGHTLY INCREASE THE CLEARANCE IN THE FRONT WISHBONE TO ALLOW SHOCK ABSORBER TO FIT. DO NOT MODIFY SHOCK ABSORBER.

## PATHFINDER (USA MODELS ONLY)

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
2005 ON	FRONT	R180A	27.8 (1.09")	27	3.69 & UP	RD180
			27.8 (1.09")	27	3.54 & DN	RD181
1987 ON		R200A	30.4 (1.20")	29	ALL	RD107
1987 ON	REAR	H233B, 31 SPLINE, 6 CYL.	32.4 (1.20")	31	ALL	RD136 <sup>2</sup>
		H233B, 33 SPLINE, 6 CYL.	33.3 (1.31")	33	ALL	RD135 <sup>2</sup>
1986-97	REAR	C200, 29 SPLINE, 4 CYL.	30.4 (1.20")	29	ALL	RD107 <sup>1,2</sup>

<sup>1</sup> ONLY SUITABLE FOR DIFFERENTIALS WITH 12MM CROWN WHEEL BOLTS.

<sup>2</sup> REFER TO DEALER OR CHECK SPLINE COUNT TO DETERMINE AXLE TYPE.