

TUNDRA

ARB DELUXE BULL BARS & WINCH BARS

YEAR	MODEL	FEATURES	WINCHES	PART NO.
1999-06	SAHARA BAR	AIRBAG APPROVED, RECESSED FOG LAMPS ¹² , URETHANE BUFFERS, TOW POINTS, SPLIT PAN	M15000, M12000	3915060 ²
2007-13	WINCH BAR	AIRBAG APPROVED, RECESSED FOG LAMPS ⁸ , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 ¹⁰	3415010 ^{3,9,11}
2007-13	SAHARA BAR	OPTIONAL ALLOY CENTER TUBE, AIRBAG APPROVED, RECESSED FOG LAMPS ⁷ , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 ¹⁰	3915030 ^{5,6,9}
2014-18	SUMMIT BAR	AIRBAG APPROVED, ARB FOG LIGHTS ¹³ RECESSED LED INDICATORS, URETHANE BUFFERS, JACK POINTS, INTEGRIT BLACK	M8000, XD9000, XP9.5, XDC9.5, ZEON 8, 10, ZEON PLAT 10,	3415020K ^{13,14,15,16}

- ¹ USES OPTIONAL IPF PART NUMBER 9381FCK
- ² DOUBLE CAB 4 DOOR MODELS REQUIRE MODIFICATIONS TO FIT BUMPER - CONTACT ARB FOR DETAILS.
- ³ FRONT SUSPENSION REQUIRED TO ACCOMMODATE THE ADDED WEIGHT OF THE ARB BUMPER
- ⁴ WILL WORK WITH OE FOG LAMPS, OR OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- ⁵ OPTIONAL CHROME CENTER TUBE REQUIRES ADDITIONAL PART #'S 5100140 AND 5115030 TO COMPLETE INSTALLATION
- ⁶ IF THE OPTIONAL CHROME CENTER TUBE IS NOT BEING INSTALLED, ADDITIONAL PART # 5100150 IS REQUIRED TO COMPLETE INSTALLATION
- ⁷ OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- ⁸ OE FOG LAMPS OR OPTIONAL IPF FOG LAMP KIT PART NUMBER 9381FCK
- ⁹ 2010+ MODELS WITH "MILLENNIUM" OR "LIMITED" GRILLS MAY NEED MODIFICATION. PLEASE CONTACT ARB FOR DETAILS (425) 264-1391
- ¹⁰ IF FITTING 12000LB WINCH, EXTRA LONG CABLE KIT 3512050 IS REQUIRED
- ¹¹ ROCK WARRIOR EDITION TUNDRA GRILL ASSEMBLIES WILL NOT CLEAR ARB BULLBARS
- ¹² OPTIONAL ARB FOG LAMP KIT PART NO. 3500590. 3500530 REQUIRED WHEN FITTING 3500590 TO MODELS WITHOUT OE FOG LAMPS
- ¹³ 3415020K KIT INCLUDES SUMMIT BUMPER, WINCH INSTALL KIT, ARB FOG LIGHT KIT AND FOG LIGHT HARNESS.
- ¹⁴ OPTIONAL HAWSE FAIRLEAD SPACER KIT PART NUMBER 3500600 REQUIRED WHEN FITTING A HAWSE FAIRLEAD.
- ¹⁵ WARN PART NO. W89965 REQUIRED WHEN FITTING WARN ZEON PLATINUM WINCH.
- ¹⁶ WARN PART NO. W94288 ENHANCED SIGNAL KIT MAY BE NEEDED WHEN FITTING WARN ZEON PLATINUM WINCH.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1999-06	FRONT	7.5" DIA. RG, 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
1999-06	REAR	8" DIA. RG, 12 BOLT	33 (1.31")	30	ALL	RD129
2007-18	FRONT	8" IFS, 58MM BEARING	35 (1.38")	34	ALL	RD151
2007-18	REAR	4.7 LITER ENGINE 9.5" DIA. RG	35 (1.37")	32	ALL	RD152
		5.7 LITER ENGINE 10.5" DIA RG				36

SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
2014-18	TOYOTA TUNDRA 5.7 V8	SS56HF

REFER TO WWW.SAFARI4x4.COM.AU FOR DETAILS.



OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2007-18	COMPLETE KITS	4.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN47LKS ⁴	
		4.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN47HKS ⁴	
		5.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN57LKS ⁴	
		5.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN57HKS ⁴	
		4.7 & 5.7L STOCK/HEAVY LOAD BP-51 KIT	KIT	2.5"	1	OMETUN57BP5 ¹⁵	
	FRONT	STOCK/LIGHT LOAD (0-150LBS)	SPRING		2.50"	1	2612
		NITROCHARGER SPORT	STRUT			2	90018
		HEAVY LOAD 4.7 LITER ENGINE (200LBS+)	SPRING		2.50"	1	2614
		NITROCHARGER SPORT	STRUT			2	90018
		HEAVY LOAD 5.7 LITER ENGINE (200LBS+)	SPRING		2.50"	1	2613
		NITROCHARGER SPORT	STRUT			2	90018
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING		2.50"	2	CS055R ³
		NITROCHARGER SPORT	SHOCK			2	60100
	REQUIRED	FITTING KIT				1	FK32 ¹
		U BOLTS				4	OMEU53B
	OPTIONAL	BP-51 COILOVER FRONT RIGHT	SHOCK	2.5"		1	BP5190010R ⁶
		BP-51 COILOVER FRONT LEFT	SHOCK	2.5"		1	BP5190010L ⁶
		BP-51 SHOCK REAR RIGHT	SHOCK			1	BP5160020R ⁷
		BP-51 SHOCK REAR LEFT	SHOCK			1	BP5160020L ⁷
		FRONT BP-51 VEHICLE MOUNT KIT	F/KIT			1	VM80010034 ⁶
		REAR BP-51 VEHICLE MOUNT KIT	F/KIT			1	VM80010035 ⁷
		SPRING BUSH KITS WHEN USED WITH OMEGS22 SHACKLES				2	OMESB106
		SPRING BUSH KITS WHEN USED WITH FACTORY SHACKLES					SEE NOTE ²
		GREASABLE SHACKLE KIT				1	OMEGS22
		EXTRA LEAF				2	D28XL

** OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

¹ FK32 FITTING KIT IS A BRAKE LINE AND ABS WIRE BRACKET RELOCATION KIT AND IS A MANDATORY FITMENT.

² NEW BONDED RUBBER BUSHES ARE SUPPLIED WITH THE LEAF SPRINGS

³ TRD MODELS WITH REAR SWAYBARS MAY REQUIRE LONGER LINKS TO RETAIN SWAYBAR OPERATION.

⁴ COMPLETE KITS CONTAIN NITROCHARGER SPORT SHOCKS & STRUTS.

⁵ COMPLETE KITS CONTAIN OME BP-51 ADJUSTABLE INTERNAL BYPASS SHOCKS AND COILOVERS.

⁶ VEHICLE MOUNTING KIT PART NUMBER **VM80010034** REQUIRED WHEN FITTING **BP5190010R/L** COILOVERS.

⁷ VEHICLE MOUNTING KIT PART NUMBER **VM80010035** REQUIRED WHEN FITTING **BP5160020R/L** SHOCKS.